

Pioneer III Console

FEATURES

- Easy Touchscreen User Interface
- 8 Access Levels (6 End-User Accessible)
- Usernames and PIN Codes for easy login
- Status, Position, and Load Readout
- Create and Build Presets, Cue Lists, and Shows
- Custom Speed-Based Cues & Ramp Times
- Illuminated Next & Load Buttons
- Manual, Targeted, and Preset Position Control
- Customizable Naming
- Jogging at Variable Speed (system dependent)
- Run Multiple Line Sets Simultaneously at Different Timings
- 20 Variable Acoustic "Looks" Available
- Hold to Run Operation
- Joystick for Precise Movement and Rate Control
- Live Rate Override During Programmed Moves
- Manual control backup system

OPTIONAL FEATURES

- Integration With Third Party Motor Systems
- Integration With AV Control Systems For Preset Recall
- Deck Boss® Scout Touchscreen Remote Control
- External E-Stop Stations
- Remote Cue Enable/Go Pendant
- Slack Line Monitoring
- Load Sensing

SYSTEM

- 22" Color Touchscreen LCD Screen
- Solid State Hard Drive
- 2 USB Ports (1 Front, 1 Rear)
- Ethernet Port
- Trackpad Input
- All Cables on Connectors
- 2 Commissioning Soft Limits Per Axis
- 10 Trim Positions Per Axis
- 999 Max Presets
- 1000+ Max Cue Numbers
- Rugged Formed Steel & Aluminum Enclosure
- Scratch Resistance Surfaces
- Dust/Splash Proof Tilt-Adjustable Display
- 24V DC Integration With Motor Control System



Pioneer III Console

LOGIN SCREEN

- Clock
- Show File Name
- Installer/Venue Logo
- Inspection Status /Counter
- Login

MOVE SCREEN

- Live Channel View
- Motor Names & Addresses
- Up/Down/Stop Manual Control

TARGETS SCREEN

- Live Channel View
- Motor Names & Addresses
- Numerical Position Readout
- Graphical Position Readout
- Numerical Target Readout
- Graphical Target Readout
- Status/Fault Condition
- Hide/Show Channels
- Target Entry
- Trim Target Selection (High and Low)
- Speed & Delay Time Readout and Editing

PRESETS SCREEN

- Machine Axis View: Axis in Preset Highlight
- Target Position for Each Included Channel
- Preset Names & Comments
- New, Copy, Delete, Load Preset

CUE STACK PROGRAMMING SCREEN

- Axis in Spreadsheet View
- Cue Name
- Cue Comment in Cue Focus View
- New, Copy, Delete, Link, Load Cue
- Programmable Speed
- Programmable Speed Override Capability
- Individual Speeds Per Axis in Per Cue
- Individual Wait Times and Speeds Per Axis

CUES SCREEN

- Channels in Spreadsheet View
- Indication of Speed in Cue Focus View
- Indication of Wait and Move Time
- Go Next Cue Ability Status Display
- Cue Comment